



EinScan H2

High Texture Resolution Handheld 3D Scanner

Hybrid Light Source LED & Infrared VCSEL Light Source



INTRO

EinScan H2



Hybrid LED & Infrared VCSEL Light Source Handheld 3D Scanner



The EinScan H2 improves on its predecessor with a **5MP** resolution texture camera, enhanced accuracy, and **3 VCSEL projectors** for more photorealistic textures and better data quality.







High Fidelity Color Reproduction

5MP texture camera

Captures rich, bright colors and clean textures for photorealistic 3D models.





Physical object






Superior Environmental Adaptability

3 Infrared VCSEL Projectors

Provide superior material and lighting adaptability, effortlessly handling various surface types and scanning environments.








High Accuracy & Versatile

Infrared VCSEL and White Light Hybrid Light Source

1. White LED Light, Visible

White LED light provides fast scanning with accurate and high quality data for professionals.

- Various scene from small to large
- Scanning speed: 1,200,000points/s
- Accuracy: Up to 0.05mm
- Point distance: Up to 0.2mm





High Accuracy & Versatile

Infrared VCSEL and White Light Hybrid Light Source

2. Infrared VCSEL Light, Invisible

Infrared VCSEL enables non-rigid algorithm for human scan and various scanning environment.

- **Dark color objects**
- **Human body scan**
- **Outdoor scan**
 - Accuracy 0.1mm
 - Point distance: Up to 0.2mm







Adjustable Working Distance & Large FOV

Enables working distance adjustment, from 200mm to 1500mm, to adapt to narrow or wide scenes more freely, and objects of various sizes much easier.

FOV (Field of View) up to **780mm** x **900mm**. Offers flexibility in scanning volume to capture large-sized objects quickly.






Advanced Algorithm for Body Scan

√ IR Mode Non-rigid Algorithm

√ Hair Enhancement

√ Flashless Scan


Captures 3D body data quickly and seamlessly, with auto-compensation of slight movements to eliminate misalignment risks. Hair mode designed to successfully capture light and dark hair.





EinScan H2

Application Industry







Prosthetic Socket



Background:

- FinScan & Luke Rehabilitation
- Traditional production method: If the prosthetic socket does not fit the residual limb properly, it can cause pain to the patient, secondary trauma to the skin or damage to the patient's bones.
- **3D digitizing method**: High-precision 3D model of the patient's residual limb can be imported into the modeling software to make the socket.












Forensic Science






Background:

- Crime scene documentation and preservation
- Management of physical evidence
- Injury analysis

Comparing with the traditional free proof, this digital method preserved the original injury information and gives a more exact and authoritative result.









CGI & VFX



Background:

- High resolution textures are essential for creating realistic and immersive environment,
- VFX artists can use the 3D model easily without a tedious post processing.











3D Digital Content



Background:

- Education: create interactive educational materials
- Advertising and marketing: high-resolution 3D digital models for use in online stores
- Heritage conservation: Visualization of artifacts or museum collections









Thank You

EinScan H2 Product Introduction

